

TX Series

OPERATION AND MAINTENANCE

MANUAL

TX Series

Low Profile Hydraulic Torque Wrenches

MODELS TX-1, TX-2, TX-4, TX-8, TX-16, TX-32, TX-45



1025 Conroy Place, Easton PA 18040 U.S.A.

Phone: +1 610-250-5800
Fax: +1 610-250-2700
Toll Free: 1-888-TORCUP-1
Email: sales@torcup.com
Website: www.torcup.com



NOTICE

Series TX-1, TX-2, TX-4, TX-8, TX-16, TX-32 and TX-45 Low Profile Hydraulic Torque Wrenches are designed for installing and removing threaded fasteners having minimal wrench clearance and requiring precise high torque during bolt makeup and maximum torque for bolt breakout.

TorcUP Inc. is not responsible for customer modification of tools for applications on which TorcUP Inc. was not consulted.

WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION IN THIS
MANUAL INTO THE HANDS OF THE OPERATOR.
FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.**

USING THE TOOL

- Always operate, inspect and maintain this tool in accordance with American National Standards Safety Code for Hydraulic Rams and Jacks (ANSI B30.1).
- This tool will function using an air or electric powered hydraulic pump. Adhere to the pump safety requirements and follow instructions when connecting the pump to the tool.
- Use only equipment rated for the same pressure and torque.
- Use only a hydraulic pump capable of generating 10,000 psi (681 bar) maximum pressure with this tool.
- Use only twin line hydraulic hose rated for 10,000 psi (681 bar) pressure with this tool.
- Do not interchange the male and female swivel inlets on the tool or the connections on one end of the hose. Reversing the inlets will reverse the power stroke cycle and may damage the tool.
- Do not use damaged, frayed or deteriorated hoses and fittings. Make certain there are no cracks, splits or leaks in the hoses.
- Use the quick connect system to attach the hoses to the tool and pump.
- When connecting hoses that have not been preloaded with hydraulic oil, make certain the pump reservoir is not drained of oil during start-up.
- Do not remove any labels. Replace any damaged label.
- Do not handle pressurized hoses. Escaping oil under pressure can penetrate the skin, causing serious injury. If oil is injected under the skin, see a doctor immediately.
- Never pressurize uncoupled couplers. Only use hydraulic equipment in a coupled system.
- Always wear eye protection when operating or performing maintenance on this tool.
- Always wear head and hand protection and protective clothing when operating this tool.

The use of other than genuine TorcUP replacement parts may result in safety hazards, decreased tool performance, increased maintenance, and may invalidate all warranties. Repairs should be made only by authorized personnel. Consult your nearest TorcUP Authorized Service Center.

Refer All Communications to the Nearest TorcUP Office or Distributor.

For Technical Support & Information Contact:
TorcUP Inc.
1025 Conroy Place, Easton, PA 18040 USA
Phone: +1 610-250-5800 Fax:+1 610-250-2700
email: sales@torcup.com

WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY

Do NOT Exceed Maximum Pressure. See Torque Chart with Tool. Damage May Occur.

Do not use damaged, frayed or deteriorated hydraulic hoses and fittings.



Always wear eye protection when operating or performing maintenance on this tool.



Always wear ear protection when operating this tool.




Do not carry the tool by the hose.



Keep body stance balanced and firm. Do not overreach when operating this tool.



The Torque Reaction Arm must be positioned against a positive stop. Do not use the arm as a dead handle. Take all precautions to make certain the operator's hand cannot be pinched between the arm and a solid object.



USING THE TOOL


- Keep hands, loose clothing and long hair away from the reaction arm and working area during operation.
- This tool will exert a strong reaction force. Use proper mechanical support and correct reaction arm positioning to control these forces. Do not position the reaction arm so that it tilts the tool off the axis of the bolt and never use the swivel inlets as a reaction stop.
- Avoid sharp bends and kinks that will cause severe back-up pressure in hoses and lead to premature hose failure.
- Use accessories recommended by TorcUP.
- Use only impact sockets and accessories. Do not use hand (chrome) sockets or accessories.
- Use only sockets and accessories that correctly fit the bolt or nut and function without tilting the tool off the axis of the bolt.
- This tool is not insulated against electric shock.
- This equipment must not be operated or serviced unless the operator read the operating instructions and fully understands the purpose, consequences and procedure of each step.
- When operating a larger tool (TX-16, TX-32, or TX-45) above waist height, employ a secondary means of support for safety purposes. A tool sling or chains may be used. Consult your safety department for further suggestions.

Depending on the working environment your local health and safety regulations may require you wear protective gear (i.e. safety shoes, hard hat, gloves, coveralls, etc.). In case external forces are exerted on the equipment, non-compliance with these regulations may result in injury. EAR PROTECTION MUST BE WORN WHEN OPERATING THIS TOOL.

PLACING THE TOOL IN SERVICE

CONNECTING THE TOOL

1. Attach the twin line hose to the swivel inlets of the square drive torque wrench using the spring-loaded quick connect ends.
2. Connect the opposite ends of the hose to the pump in the same manner.
3. Push the link retaining pin out of the low profile drive cylinder.
4. Mate the selected ratchet link to the cylinder by inserting the end of the cylinder opposite the swivel inlets between the side plates of the ratchet link. (Refer to Dwg. 1)
5. Align the holes for the link retaining pin and insert the pin through the side plates and cylinder to keep the units joined together.



SETTING THE TORQUE


After determining the desired torque, use the torque conversion charts on pages 7 to 20 to determine the pressure that is necessary to achieve that torque.

1. Connect the tool to the power supply and turn the pump on.
2. Depress the remote control button causing the pressure to be shown on the gauge.
3. Adjust the pressure by loosening the wing nut that locks the pressure adjustment thumbscrew. Rotate the thumbscrew clockwise to increase the pressure and counterclockwise to decrease the pressure. When decreasing pressure, always lower the pressure below the desired point and then bring the gauge back up to the desired pressure.
4. When the desired pressure is reached, retighten the wing nut and cycle the tool again to confirm that the desired pressure setting has been obtained.

OPERATING THE WRENCH

The position of the tool relative to the nut determines whether the action will tighten or loosen the nut. (Refer to Dwg. 2 for application examples). The power stroke of the piston assembly will always turn the ratchet hex toward the shroud.

1. Place the ratchet hex on the nut. Make certain it is the correct size for the nut and that it fully engages the nut.
2. Position the reaction surface against an adjacent nut, flange or solid system component. Make certain that there is clearance for the hoses, swivels, and inlets. **DO NOT** allow the tool to react against the hoses, swivels, or inlets.



PLACING THE TOOL IN SERVICE

3. After having turned the pump on and presetting the pressure for the correct torque, depress the remote control button to advance the piston assembly. If the notch in the piston rod did not engage the retract pin in the ratchet link when the link was joined to the housing, it will engage the pin automatically during the first advance stroke.
4. When the link is connected to the cylinder and the wrench is started, the reaction surface of the wrench will move against the contact point and the nut will begin to turn.
5. When the nut is no longer turning and the pump gauge reaches the preset pressure, release the remote control button. The piston rod will retract when the button is released. Under normal conditions, an audible "click" will be heard as the tool resets itself.
6. Continue to cycle the tool until it "stalls" and the preset psi/torque has been attained.
7. Cycle the tool one last time to ensure full total torque.


LUBRICATION

MARINE MOLY GREASE

Lubrication frequency is dependent on factors known only to the user. The amount of contaminants in the work area is one factor. Tools used in a clean room environment will obviously require less service than a tool used outdoors and dropped in loose dirt or sand. Marine Moly Grease is formulated not to wash out of the tool in areas where lubrication is critical. Whenever lubrication is required, lubricate as follows:


1. Separate the low profile cylinder from the ratchet link if they are joined.
2. After wiping off the old grease, apply a daub of Marine Moly Grease to the hooking notch on the piston rod and wipe a film of Marine Moly Grease onto the sides and faces of the two sliders.
3. Disassemble the ratchet link as instructed in the Maintenance Section and wash the components in a suitable cleaning solution in a well ventilated area.
4. Dry the components, then wipe a film of Marine Moly Grease onto the wear surface of both side plate sleeves and the hubs of the ratchet.
5. Spread a light film of Marine Moly Grease onto the inner faces of both side plates covering the area where the drive plate and drive segment travel. DO NOT pack the teeth of the drive segment or ratchet with lube. It can prevent the teeth from engaging properly.
6. Reassemble the ratchet link as instructed in the Maintenance Section.

TX Series Wrench Technical & Dimensional Data



Model Number	TX-1	TX-2	TX-4	TX-8
Min. Torque (ft/lbs)	45	192	395	830
Max. Torque (ft/lbs)	560	1928	3950	8630
Min. Torque (nm)	61	260	535	1125
Max. Torque (nm)	759	2614	5355	11699
Output Accuracy	+/-3%	+/-3%	+/-3%	+/-3%
Repeatability	100%	100%	100%	100%
Duty Cycle	100%	100%	100%	100%
Cylinder Weight (lbs/kg)	1.0/0.5	3.5/1.6	6.0/2.7	11.7/5.0
Link Weight (lbs) (kg)	1.0-1.0 0.45-0.45	2.4-3.5 1.0-1.5	5.4-7.6 2.4-3.4	11.9-14.5 5.5-6.5
Length (in/mm)	4.37/111.0	6.45/163.8	7.87/199.9	10.18/258.6
Width (in/mm)	0.78/19.8	1.25/31.8	1.63/41.4	2.05/52.1
Radius (in/mm)	0.23/5.8	0.36/9.1	0.46/11.7	0.54/13.7
Height (in/mm)	3.25/82.6	4.00/101.6	5.60/142.2	7.00/177.8
Hex Range From	1/2"/13mm	3/4"/19mm	1"/27mm	1 7/8"/49mm
Hex Range To	2"/50mm	2 9/16"/65mm	3 1/8"/80mm	4 5/8"/120mm

TX Series Wrench Technical & Dimensional Data



Model Number	TX-16	TX-32	TX-45
Min. Torque (ft/lbs)	1560	3220	4850
Max. Torque (ft/lbs)	16600	35650	47380
Min. Torque (nm)	2115	4365	6575
Max. Torque (nm)	22503	48327	64239
Output Accuracy	+/-3%	+/-3%	+/-3%
Repeatability	100%	100%	100%
Duty Cycle	100%	100%	100%
Cylinder Weight (lbs/kg)	16.0/7.3	26.0/11.5	29.0/13.0
Link Weight (lbs) (kg)	21.0-28.0 9.5-13.0	29.0-39.5 13.0-17.9	29.0-39.5 13.0-17.9
Length (in/mm)	12.93/328.4	15.80/401.3	16.75/425.5
Width (in/mm)	2.50/63.5	3.24/82.3	4.88/124.0
Radius (in/mm)	0.65/16.5	0.93/23.6	0.93/23.6
Height (in/mm)	7.58/192.5	9.50/241.3	10.28/261.1
Hex Range From	2 3/16"/55mm	3 1/8"/80mm	3 1/8"/80mm
Hex Range To	5 5/16"/135mm	7 7/8"/200mm	7 7/8"/200mm



TORCUP

TX-1 Torque Conversion Chart (Imperial)

Imperial Conversion	
PSI	Ft-lbs
1,000	55
1,200	64
1,400	74
1,600	83
1,800	92
2,000	101
2,200	110
2,400	119
2,600	129
2,800	138
3,000	147
3,200	156
3,400	165
3,600	174
3,800	182
4,000	191
4,200	200
4,400	209
4,600	218
4,800	227
5,000	236
5,200	245
5,400	254
5,600	264
5,800	273
6,000	282
6,200	291
6,400	300
6,600	309
6,800	318
7,000	327
7,200	336
7,400	344
7,600	353
7,800	362
8,000	371
8,200	380
8,400	389
8,600	399
8,800	408
9,000	417
9,200	426
9,400	435
9,600	443
9,800	452
10,000	461

Hex Range 1 1/2"- 1 1/8"

Imperial Conversion	
PSI	Ft-lbs
1,000	71
1,200	83
1,400	95
1,600	106
1,800	118
2,000	130
2,200	142
2,400	154
2,600	165
2,800	177
3,000	189
3,200	200
3,400	212
3,600	223
3,800	235
4,000	246
4,200	258
4,400	269
4,600	281
4,800	292
5,000	304
5,200	316
5,400	327
5,600	339
5,800	350
6,000	362
6,200	374
6,400	385
6,600	397
6,800	408
7,000	420
7,200	431
7,400	443
7,600	454
7,800	466
8,000	477
8,200	489
8,400	501
8,600	512
8,800	524
9,000	536
9,200	547
9,400	559
9,600	570
9,800	582
10,000	593

Hex Range 1 3/16"- 1 13/16"

Imperial Conversion	
PSI	Ft-lbs
1,000	79
1,200	92
1,400	105
1,600	118
1,800	131
2,000	144
2,200	158
2,400	171
2,600	184
2,800	197
3,000	210
3,200	223
3,400	235
3,600	248
3,800	261
4,000	273
4,200	286
4,400	299
4,600	312
4,800	325
5,000	338
5,200	351
5,400	364
5,600	376
5,800	389
6,000	402
6,200	415
6,400	428
6,600	441
6,800	454
7,000	467
7,200	479
7,400	492
7,600	505
7,800	517
8,000	530
8,200	543
8,400	556
8,600	569
8,800	582
9,000	596
9,200	608
9,400	621
9,600	634
9,800	646
10,000	659

Hex Range 1 7/8"- 2"

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-1 Torque Conversion Chart (Metric)

Metric Conversion	
Bar	Nm
69	75
83	87
97	100
110	112
124	125
138	137
152	150
165	162
179	174
193	187
207	199
221	211
234	223
248	235
262	247
276	259
290	272
303	284
317	296
331	308
345	321
359	333
372	345
386	357
400	370
414	382
427	394
441	406
455	418
469	431
483	443
496	455
510	467
524	479
538	491
552	503
565	515
579	528
593	540
607	553
621	565
634	577
648	589
662	601
676	613
689	625

Metric Conversion	
Bar	Nm
69	96
83	112
97	128
110	144
124	160
138	176
152	192
165	208
179	224
193	240
207	256
221	272
234	287
248	303
262	318
276	334
290	349
303	365
317	381
331	396
345	412
359	428
372	444
386	459
400	475
414	491
427	507
441	522
455	538
469	554
483	569
496	585
510	600
524	616
538	631
552	647
565	663
579	679
593	695
607	711
621	727
634	742
648	758
662	773
676	789
689	804

Metric Conversion	
Bar	Nm
69	107
83	125
97	143
110	160
124	178
138	196
152	214
165	231
179	249
193	267
207	285
221	302
234	319
248	336
262	353
276	371
290	388
303	406
317	423
331	440
345	458
359	475
372	493
386	510
400	528
414	545
427	563
441	580
455	598
469	615
483	633
496	650
510	667
524	684
538	701
552	719
565	736
579	754
593	772
607	790
621	807
634	825
648	842
662	859
676	876
689	893

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-2 Torque Conversion Chart (Imperial)

Imperial Conversion	
PSI	Ft-lbs
1,000	202
1,200	240
1,400	278
1,600	317
1,800	355
2,000	393
2,200	432
2,400	471
2,600	511
2,800	550
3,000	589
3,200	629
3,400	669
3,600	708
3,800	748
4,000	788
4,200	827
4,400	867
4,600	906
4,800	946
5,000	985
5,200	1024
5,400	1064
5,600	1103
5,800	1142
6,000	1182
6,200	1222
6,400	1261
6,600	1301
6,800	1341
7,000	1381
7,200	1421
7,400	1461
7,600	1500
7,800	1540
8,000	1579
8,200	1619
8,400	1658
8,600	1697
8,800	1737
9,000	1776
9,200	1814
9,400	1853
9,600	1892
9,800	1930
10,000	1969

Imperial Conversion	
PSI	Ft-lbs
1,000	237
1,200	282
1,400	326
1,600	371
1,800	415
2,000	460
2,200	506
2,400	552
2,600	598
2,800	644
3,000	690
3,200	737
3,400	783
3,600	830
3,800	876
4,000	923
4,200	969
4,400	1015
4,600	1062
4,800	1108
5,000	1154
5,200	1200
5,400	1246
5,600	1292
5,800	1338
6,000	1384
6,200	1431
6,400	1478
6,600	1524
6,800	1571
7,000	1618
7,200	1664
7,400	1711
7,600	1757
7,800	1804
8,000	1850
8,200	1896
8,400	1942
8,600	1988
8,800	2034
9,000	2080
9,200	2125
9,400	2170
9,600	2216
9,800	2261
10,000	2306

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-2 Torque Conversion Chart (Metric)

	Metric Conversion		
	Bar	Nm	
	69	274	69
Hex Range 19-46mm	83	326	83
	97	378	97
	110	429	110
	124	481	124
	138	532	138
	152	586	152
	165	639	165
	179	692	179
	193	745	193
	207	799	207
Hex Range 47-65mm	221	853	221
	234	907	234
	248	961	248
	262	1014	262
	276	1068	276
	290	1122	290
	303	1175	303
	317	1229	317
	331	1282	331
	345	1336	345
Hex Range 19-46mm	359	1389	359
	372	1442	372
	386	1496	386
	400	1549	400
	414	1602	414
	427	1656	427
	441	1710	441
	455	1765	455
	469	1819	469
	483	1873	483
Hex Range 47-65mm	496	1927	496
	510	1980	510
	524	2034	524
	538	2088	538
	552	2141	552
	565	2195	565
	579	2248	579
	593	2301	593
	607	2354	607
	621	2408	621
Hex Range 19-46mm	634	2460	634
	648	2512	648
	662	2565	662
	676	2617	676
	689	2669	689
			2445
			2508
			2571
			2633
			2695
Hex Range 47-65mm			2758
			2820
			2881
			2943
			3004
			3065
			3127

For reference purposes only, please consult the calibration chart specific to your purchase or rental.



TORCUP

TX-4 Torque Conversion Chart (Imperial)

	Imperial Conversion	
	PSI	Ft-lbs
Hex Range 1"- 2 9/16"	1,000	422
	1,200	502
	1,400	582
	1,600	663
	1,800	743
	2,000	823
	2,200	906
	2,400	989
	2,600	1072
	2,800	1155
	3,000	1238
	3,200	1320
	3,400	1401
	3,600	1483
	3,800	1564
	4,000	1646
	4,200	1726
	4,400	1806
	4,600	1887
	4,800	1967
Hex Range 2 5/8"- 3 1/8"	5,000	2047
	5,200	2128
	5,400	2209
	5,600	2289
	5,800	2370
	6,000	2451
	6,200	2533
	6,400	2615
	6,600	2698
	6,800	2780
	7,000	2862
	7,200	2942
	7,400	3021
	7,600	3101
	7,800	3180
	8,000	3260
	8,200	3343
	8,400	3426
	8,600	3510
	8,800	3593
	9,000	3676
	9,200	3758
	9,400	3840
	9,600	3922
	9,800	4004
	10,000	4086

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-4 Torque Conversion Chart (Metric)

Metric Conversion	
Bar	Nm
69	572
83	681
97	790
110	898
124	1007
138	1116
152	1228
165	1341
179	1453
193	1566
207	1679
221	1789
234	1900
248	2010
262	2121
276	2232
290	2340
303	2449
317	2558
331	2667
345	2775
359	2885
372	2994
386	3104
400	3214
414	3323
427	3435
441	3546
455	3657
469	3769
483	3880
496	3988
510	4096
524	4204
538	4312
552	4420
565	4533
579	4646
593	4758
607	4871
621	4984
634	5095
648	5206
662	5318
676	5429
689	5540

Metric Conversion	
Bar	Nm
69	644
83	766
97	888
110	1011
124	1133
138	1255
152	1382
165	1508
179	1635
193	1761
207	1888
221	2013
234	2137
248	2261
262	2386
276	2510
290	2633
303	2755
317	2877
331	3000
345	3122
359	3245
372	3368
386	3492
400	3615
414	3738
427	3863
441	3989
455	4114
469	4239
483	4365
496	4486
510	4608
524	4729
538	4850
552	4972
565	5099
579	5226
593	5352
607	5479
621	5606
634	5731
648	5856
662	5981
676	6107
689	6232

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-8 Torque Conversion Chart (Imperial)

Imperial Conversion	
PSI	Ft-lbs
1,000	797
1,200	957
1,400	1117
1,600	1277
1,800	1437
2,000	1597
2,200	1758
2,400	1918
2,600	2079
2,800	2239
3,000	2400
3,200	2559
3,400	2719
3,600	2878
3,800	3037
4,000	3197
4,200	3354
4,400	3511
4,600	3668
4,800	3825
5,000	3982
5,200	4143
5,400	4303
5,600	4463
5,800	4623
6,000	4784
6,200	4946
6,400	5109
6,600	5272
6,800	5434
7,000	5597
7,200	5756
7,400	5916
7,600	6076
7,800	6236
8,000	6395
8,200	6564
8,400	6732
8,600	6900
8,800	7068
9,000	7236
9,200	7393
9,400	7551
9,600	7709
9,800	7866
10,000	8024

Imperial Conversion	
PSI	Ft-lbs
1,000	842
1,200	1011
1,400	1180
1,600	1350
1,800	1519
2,000	1688
2,200	1858
2,400	2027
2,600	2197
2,800	2366
3,000	2536
3,200	2704
3,400	2873
3,600	3041
3,800	3210
4,000	3378
4,200	3544
4,400	3710
4,600	3876
4,800	4042
5,000	4208
5,200	4377
5,400	4547
5,600	4716
5,800	4886
6,000	5055
6,200	5227
6,400	5399
6,600	5570
6,800	5742
7,000	5914
7,200	6083
7,400	6252
7,600	6420
7,800	6589
8,000	6758
8,200	6936
8,400	7113
8,600	7291
8,800	7468
9,000	7646
9,200	7813
9,400	7979
9,600	8146
9,800	8312
10,000	8479

Imperial Conversion	
PSI	Ft-lbs
1,000	978
1,200	1174
1,400	1370
1,600	1567
1,800	1763
2,000	1960
2,200	2157
2,400	2353
2,600	2550
2,800	2747
3,000	2944
3,200	3140
3,400	3335
3,600	3531
3,800	3726
4,000	3922
4,200	4114
4,400	4307
4,600	4500
4,800	4693
5,000	4885
5,200	5082
5,400	5279
5,600	5475
5,800	5672
6,000	5869
6,200	6068
6,400	6267
6,600	6467
6,800	6666
7,000	6866
7,200	7062
7,400	7258
7,600	7454
7,800	7650
8,000	7846
8,200	8052
8,400	8258
8,600	8464
8,800	8670
9,000	8877
9,200	9070
9,400	9263
9,600	9457
9,800	9650
10,000	9844

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-8 Torque Conversion Chart (Metric)

Metric Conversion		Metric Conversion		Metric Conversion	
Bar	Nm	Bar	Nm	Bar	Nm
69	1080	69	1142	69	1325
83	1297	83	1371	83	1592
97	1515	97	1600	97	1858
110	1732	110	1830	110	2124
124	1949	124	2059	124	2391
138	2166	138	2289	138	2657
152	2383	152	2519	152	2924
165	2601	165	2749	165	3191
179	2819	179	2978	179	3458
193	3036	193	3208	193	3725
207	3254	207	3438	207	3992
221	3470	221	3667	221	4257
234	3686	234	3895	234	4522
248	3902	248	4123	248	4787
262	4118	262	4352	262	5052
276	4334	276	4580	276	5317
290	4547	290	4805	290	5578
303	4760	303	5030	303	5840
317	4973	317	5255	317	6101
331	5186	331	5480	331	6362
345	5399	345	5705	345	6624
359	5617	359	5935	359	6890
372	5834	372	6165	372	7157
386	6051	386	6394	386	7423
400	6269	400	6624	400	7690
414	6486	414	6854	414	7957
427	6706	427	7087	427	8227
441	6927	441	7320	441	8498
455	7147	455	7552	455	8768
469	7368	469	7785	469	9038
483	7588	483	8018	483	9309
496	7805	496	8247	496	9575
510	8021	510	8476	510	9840
524	8238	524	8705	524	10106
538	8454	538	8934	538	10372
552	8671	552	9163	552	10637
565	8899	565	9403	565	10917
579	9127	579	9644	579	11196
593	9355	593	9885	593	11476
607	9583	607	10126	607	11755
621	9810	621	10367	621	12035
634	10024	634	10592	634	12297
648	10238	648	10818	648	12559
662	10452	662	11044	662	12822
676	10665	676	11270	676	13084
689	10879	689	11496	689	13346

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-16 Torque Conversion Chart (Imperial)

Imperial Conversion	
PSI	Ft-lbs
1,000	1627
1,200	1931
1,400	2234
1,600	2538
1,800	2842
2,000	3145
2,200	3448
2,400	3752
2,600	4055
2,800	4358
3,000	4661
3,200	4965
3,400	5269
3,600	5573
3,800	5876
4,000	6180
4,200	6483
4,400	6785
4,600	7087
4,800	7389
5,000	7692
5,200	8001
5,400	8311
5,600	8620
5,800	8930
6,000	9239
6,200	9553
6,400	9866
6,600	10180
6,800	10494
7,000	10808
7,200	11111
7,400	11415
7,600	11719
7,800	12023
8,000	12326
8,200	12646
8,400	12966
8,600	13286
8,800	13606
9,000	13926
9,200	14245
9,400	14563
9,600	14881
9,800	15200
10,000	15518

Hex Range 2 3/16"- 3 15/16"

Imperial Conversion	
PSI	Ft-lbs
1,000	1773
1,200	2104
1,400	2435
1,600	2765
1,800	3096
2,000	3427
2,200	3757
2,400	4088
2,600	4418
2,800	4749
3,000	5079
3,200	5410
3,400	5741
3,600	6072
3,800	6403
4,000	6734
4,200	7063
4,400	7393
4,600	7722
4,800	8052
5,000	8381
5,200	8718
5,400	9055
5,600	9393
5,800	9730
6,000	10067
6,200	10409
6,400	10751
6,600	11092
6,800	11434
7,000	11776
7,200	12107
7,400	12438
7,600	12769
7,800	13100
8,000	13431
8,200	13780
8,400	14128
8,600	14477
8,800	14825
9,000	15174
9,200	15521
9,400	15868
9,600	16215
9,800	16562
10,000	16909

Hex Range 4"- 4 11/16"

Imperial Conversion	
PSI	Ft-lbs
1,000	2075
1,200	2462
1,400	2849
1,600	3236
1,800	3623
2,000	4011
2,200	4397
2,400	4784
2,600	5170
2,800	5557
3,000	5944
3,200	6331
3,400	6719
3,600	7106
3,800	7493
4,000	7881
4,200	8266
4,400	8652
4,600	9037
4,800	9423
5,000	9808
5,200	10203
5,400	10597
5,600	10992
5,800	11387
6,000	11781
6,200	12181
6,400	12581
6,600	12981
6,800	13381
7,000	13781
7,200	14168
7,400	14556
7,600	14943
7,800	15331
8,000	15718
8,200	16126
8,400	16534
8,600	16942
8,800	17350
9,000	17758
9,200	18164
9,400	18570
9,600	18976
9,800	19382
10,000	19788

Hex Range 4 3/4"- 5 5/16"

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-16 Torque Conversion Chart (Metric)

Metric Conversion	
Bar	Nm
69	2206
83	2618
97	3029
110	3441
124	3853
138	4264
152	4675
165	5087
179	5498
193	5909
207	6320
221	6732
234	7144
248	7555
262	7967
276	8379
290	8789
303	9199
317	9609
331	10019
345	10429
359	10848
372	11268
386	11687
400	12107
414	12527
427	12952
441	13377
455	13802
469	14228
483	14653
496	15065
510	15477
524	15889
538	16301
552	16712
565	17146
579	17580
593	18014
607	18447
621	18881
634	19313
648	19745
662	20177
676	20608
689	21040

Metric Conversion	
Bar	Nm
69	2404
83	2852
97	3301
110	3749
124	4198
138	4646
152	5094
165	5542
179	5990
193	6438
207	6886
221	7335
234	7784
248	8233
262	8681
276	9130
290	9577
303	10023
317	10470
331	10917
345	11363
359	11820
372	12277
386	12735
400	13192
414	13649
427	14112
441	14576
455	15039
469	15503
483	15966
496	16415
510	16864
524	17312
538	17761
552	18210
565	18683
579	19155
593	19628
607	20101
621	20573
634	21044
648	21514
662	21985
676	22455
689	22926

Metric Conversion	
Bar	Nm
69	2813
83	3338
97	3863
110	4388
124	4913
138	5438
152	5962
165	6486
179	7010
193	7534
207	8059
221	8584
234	9109
248	9634
262	10159
276	10685
290	11207
303	11730
317	12253
331	12775
345	13298
359	13833
372	14368
386	14903
400	15438
414	15973
427	16515
441	17058
455	17600
469	18142
483	18685
496	19210
510	19735
524	20260
538	20785
552	21311
565	21864
579	22417
593	22970
607	23523
621	24076
634	24627
648	25177
662	25728
676	26278
689	26829

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-32 Torque Conversion Chart (Imperial)

	Imperial Conversion			Imperial Conversion			Imperial Conversion	
	PSI	Ft-lbs		PSI	Ft-lbs		PSI	Ft-lbs
Hex Range 3 1/8" - 4 5/8"	1,000	3472		1,000	3844		1,000	4340
	1,200	4132		1,200	4574		1,200	5165
	1,400	4791		1,400	5305		1,400	5989
	1,600	5451		1,600	6035		1,600	6814
	1,800	6111		1,800	6766		1,800	7639
	2,000	6771		2,000	7496		2,000	8463
	2,200	7422		2,200	8217		2,200	9277
	2,400	8073		2,400	8938		2,400	10091
	2,600	8724		2,600	9658		2,600	10905
	2,800	9375		2,800	10379		2,800	11718
Hex Range 4 11/16" - 6 1/2"	3,000	10026		3,000	11100		3,000	12532
	3,200	10684		3,200	11829		3,200	13355
	3,400	11342		3,400	12558		3,400	14178
	3,600	12001		3,600	13286		3,600	15001
	3,800	12659		3,800	14015		3,800	15824
	4,000	13317		4,000	14744		4,000	16646
	4,200	13967		4,200	15464		4,200	17459
	4,400	14618		4,400	16184		4,400	18272
	4,600	15268		4,600	16904		4,600	19085
	4,800	15918		4,800	17624		4,800	19898
Hex Range 6 9/16" - 7 7/8"	5,000	16569		5,000	18344		5,000	20711
	5,200	17222		5,200	19068		5,200	21528
	5,400	17876		5,400	19791		5,400	22345
	5,600	18529		5,600	20515		5,600	23162
	5,800	19183		5,800	21238		5,800	23979
	6,000	19837		6,000	21962		6,000	24796
	6,200	20497		6,200	22693		6,200	25621
	6,400	21157		6,400	23424		6,400	26446
	6,600	21817		6,600	24154		6,600	27271
	6,800	22477		6,800	24885		6,800	28096
Hex Range 7 1/2" - 8 1/2"	7,000	23137		7,000	25616		7,000	28921
	7,200	23786		7,200	26334		7,200	29732
	7,400	24435		7,400	27053		7,400	30543
	7,600	25084		7,600	27771		7,600	31355
	7,800	25733		7,800	28490		7,800	32166
	8,000	26381		8,000	29208		8,000	32977
	8,200	27032		8,200	29928		8,200	33790
	8,400	27683		8,400	30649		8,400	34603
	8,600	28333		8,600	31369		8,600	35417
	8,800	28984		8,800	32090		8,800	36230
Hex Range 8 1/2" - 9 1/2"	9,000	29635		9,000	32810		9,000	37044
	9,200	30287		9,200	33532		9,200	37859
	9,400	30940		9,400	34255		9,400	38675
	9,600	31592		9,600	34977		9,600	39490
	9,800	32245		9,800	35700		9,800	40306
	10,000	32897		10,000	36422		10,000	41122

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-32 Torque Conversion Chart (Metric)

Metric Conversion	
Bar	Nm
69	4707
83	5602
97	6496
110	7391
124	8285
138	9180
152	10062
165	10945
179	11828
193	12710
207	13593
221	14486
234	15378
248	16271
262	17163
276	18056
290	18937
303	19819
317	20701
331	21583
345	22464
359	23350
372	24236
386	25123
400	26009
414	26895
427	27790
441	28685
455	29580
469	30475
483	31370
496	32249
510	33129
524	34009
538	34889
552	35768
565	36651
579	37533
593	38415
607	39297
621	40179
634	41064
648	41949
662	42833
676	43718
689	44603

Metric Conversion	
Bar	Nm
69	5212
83	6202
97	7192
110	8183
124	9173
138	10163
152	11140
165	12118
179	13095
193	14072
207	15050
221	16038
234	17026
248	18014
262	19002
276	19990
290	20966
303	21943
317	22919
331	23895
345	24871
359	25852
372	26833
386	27814
400	28795
414	29776
427	30767
441	31758
455	32749
469	33740
483	34731
496	35705
510	36679
524	37653
538	38627
552	39601
565	40577
579	41554
593	42531
607	43508
621	44484
634	45464
648	46443
662	47423
676	48402
689	49382

Metric Conversion	
Bar	Nm
69	5884
83	7002
97	8120
110	9238
124	10357
138	11475
152	12578
165	13681
179	14785
193	15888
207	16991
221	18107
234	19223
248	20338
262	21454
276	22570
290	23672
303	24774
317	25876
331	26978
345	28080
359	29188
372	30296
386	31403
400	32511
414	33619
427	34737
441	35856
455	36975
469	38093
483	39212
496	40312
510	41411
524	42511
538	43611
552	44711
565	45813
579	46916
593	48019
607	49122
621	50224
634	51330
648	52436
662	53542
676	54648
689	55753

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-45 Torque Conversion Chart (Imperial)

	Imperial Conversion			Imperial Conversion			Imperial Conversion	
	PSI	Ft-lbs		PSI	Ft-lbs		PSI	Ft-lbs
Hex Range 3 1/8" - 4 5/8"	1,000	4543		1,000	5030		1,000	5679
	1,200	5460		1,200	6045		1,200	6825
	1,400	6377		1,400	7061		1,400	7972
	1,600	7295		1,600	8076		1,600	9118
	1,800	8212		1,800	9092		1,800	10265
	2,000	9129		2,000	10107		2,000	11411
	2,200	10023		2,200	11097		2,200	12529
	2,400	10918		2,400	12088		2,400	13648
	2,600	11813		2,600	13078		2,600	14766
	2,800	12707		2,800	14069		2,800	15884
	3,000	13602		3,000	15059		3,000	17002
	3,200	14506		3,200	16061		3,200	18133
	3,400	15411		3,400	17062		3,400	19264
	3,600	16316		3,600	18064		3,600	20395
	3,800	17220		3,800	19065		3,800	21525
	4,000	18125		4,000	20067		4,000	22656
	4,200	19026		4,200	21064		4,200	23782
	4,400	19926		4,400	22061		4,400	24908
	4,600	20827		4,600	23058		4,600	26033
	4,800	21727		4,800	24055		4,800	27159
	5,000	22628		5,000	25052		5,000	28285
	5,200	23528		5,200	26049		5,200	29410
	5,400	24429		5,400	27046		5,400	30536
	5,600	25330		5,600	28044		5,600	31662
	5,800	26230		5,800	29041		5,800	32788
	6,000	27131		6,000	30038		6,000	33914
	6,200	28033		6,200	31037		6,200	35041
	6,400	28935		6,400	32035		6,400	36169
	6,600	29837		6,600	33034		6,600	37296
	6,800	30739		6,800	34032		6,800	38424
	7,000	31641		7,000	35031		7,000	39551
	7,200	32542		7,200	36029		7,200	40677
	7,400	33443		7,400	37026		7,400	41804
	7,600	34344		7,600	38024		7,600	42930
	7,800	35245		7,800	39021		7,800	44056
	8,000	36146		8,000	40019		8,000	45183
	8,200	37047		8,200	41017		8,200	46309
	8,400	37949		8,400	42015		8,400	47436
	8,600	38850		8,600	43012		8,600	48562
	8,800	39751		8,800	44010		8,800	49689
	9,000	40652		9,000	45008		9,000	50815
	9,200	41553		9,200	46005		9,200	51941
	9,400	42453		9,400	47002		9,400	53067
	9,600	43354		9,600	47999		9,600	54192
	9,800	44254		9,800	48996		9,800	55318
	10,000	45155		10,000	49993		10,000	56444

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TX-45 Torque Conversion Chart (Metric)


Metric Conversion	
Bar	Nm
69	6160
83	7403
97	8647
110	9890
124	11134
138	12377
152	13590
165	14803
179	16016
193	17229
207	18441
221	19668
234	20895
248	22121
262	23348
276	24574
290	25795
303	27016
317	28237
331	29458
345	30679
359	31900
372	33121
386	34342
400	35564
414	36785
427	38008
441	39231
455	40454
469	41676
483	42899
496	44121
510	45343
524	46564
538	47786
552	49008
565	50230
579	51451
593	52673
607	53895
621	55117
634	56338
648	57559
662	58780
676	60001
689	61222

Metric Conversion	
Bar	Nm
69	6820
83	8196
97	9573
110	10950
124	12327
138	13703
152	15046
165	16389
179	17732
193	19074
207	20417
221	21775
234	23133
248	24491
262	25849
276	27207
290	28559
303	29911
317	31262
331	32614
345	33966
359	35318
372	36670
386	38022
400	39374
414	40726
427	42080
441	43434
455	44788
469	46142
483	47496
496	48848
510	50201
524	51553
538	52906
552	54258
565	55611
579	56964
593	58317
607	59670
621	61023
634	62374
648	63726
662	65078
676	66430
689	67781

Metric Conversion	
Bar	Nm
69	7700
83	9254
97	10808
110	12363
124	13917
138	15471
152	16987
165	18504
179	20020
193	21536
207	23052
221	24585
234	26118
248	27651
262	29185
276	30718
290	32244
303	33770
317	35296
331	36822
345	38349
359	39875
372	41402
386	42928
400	44455
414	45981
427	47510
441	49038
455	50567
469	52096
483	53624
496	55151
510	56678
524	58205
538	59732
552	61260
565	62787
579	64314
593	65842
607	67369
621	68897
634	70423
648	71949
662	73475
676	75001
689	76527

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TX-1 Series Cylinder




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Housing	TX-1-C01	1
2A	Piston Rod	TX-1-C03-1	1
2B	Piston Cap	TX-1-C03-2	1
6	Slider	TX-1-C09	2
7	End Cap	TX-1-C11	1
9	Link Pin	TX-1-C15	1
12	Plunger	TX-1-C25	1
13	Plunger Spring	TX-1-C26	1
14	Slider Pin	TX-1-C27	1
15	Plunger Pin	TX-1-C28	1
16	End Plug Seal	TX-1-C29	1
17	Rod Seal	TX-1-C31	1
19	Piston Seal	TX-1-C33	1
20	Rod Bushing	TX-1-C51	1
26	Whip Hose - 16"	HPH-16"-1/8	2
28	Coupler Set	HC-S-100	1

Piston Assembly (2A & 2B)

TX-1-C03

TX-1 Series Link




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Side Plate - Left	TX-1-L01- #*	1
2	Side Plate - Right	TX-1-L02- #*	1
3	Drive Plate	TX-1-L03- #*	1
4	Drive Pin	TX-1-L05	1
5	Drive Pin Spring	TX-1-L07	1
6	Ratchet	TX-1-L09- #*	1
7	Drive Segment	TX-1-L11- #*	1
11	Spacer Pin	TX-1-L17	3
12	Sideplate Sleeves	TX-1-L19- #*	2
14	Segment Spring	TX-1-L25	1
15	Side Plate Screws	TX-1-L29	3
16	Dr. Pin Spring Roll Pin	TX-1-L33	1

*part number is dependent upon ratchet link size


TX-2 Series Cylinder



Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Housing	TX-2-C01	1
2	Piston	TX-2-C03	1
6	Slider	TX-2-C09	2
7	End Cap	TX-2-C11	1
8	Retaining Ring	TX-2-C13	2
9	Link Pin	TX-2-C15	1
10	End Cover	TX-2-C17	1
11	End Cover Screw	TX-2-C23	1
14	Slider Pin	TX-2-C27	1
16	End Plug Seal	TX-2-C29	1
17	Rod Seal	TX-2-C31	1
19	Piston Seal	TX-2-C33	1
21	Link Retaining Spring	TX-2-C53	1
27	Swivel Assembly	STX-8M-4M	2
28	Coupler Set	HC-S-100	1
40	Seal Insertion Tool	ATX-2-ST	

TX-2 Series Link




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Side Plate - Left	TX-2-L01- #*	1
2	Side Plate - Right	TX-2-L02- #*	1
3	Drive Plate	TX-2-L03- #*	1
4	Drive Pin	TX-2-L05	1
5	Drive Pin Spring	TX-2-L07	1
6	Ratchet	TX-2-L09- #*	1
7	Drive Segment	TX-2-L11- #*	1
8	Upper Spacer	TX-2-L13- #*	1
10	Lower Spacer	TX-2-L15- #*	1
11	Spacer Pin	TX-2-L17	2
12	Sideplate Sleeve	TX-2-L19- #*	2
13	Shroud	TX-2-L21	1
14	Segment Spring	TX-2-L25	1
15	Upper Spacer Screw	TX-2-L27	4
16	Lower Spacer Screw	TX-2-L29	4
17	Shroud Screw	TX-2-L31	2
18	Dr. Pin Spring Roll Pin	TX-2-L33	1

*part number is dependent upon ratchet link size


TX-4 Series Cylinder



Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Housing	TX-4-C01	1
2	Piston	TX-4-C03	1
6	Slider	TX-4-C09	2
7	End Cap	TX-4-C11	1
8	Retaining Ring	TX-4-C13	2
9	Link Pin	TX-4-C15	1
10	End Cover	TX-4-C17	1
11	End Cover Screw	TX-4-C23	1
14	Slider Pin	TX-4-C27	1
16	End Plug Seal	TX-4-C29	1
17	Rod Seal	TX-4-C31	1
19	Piston Seal	TX-4-C33	1
20	Cylinder Gland	TX-4-C51	1
21	Link Retaining Spring	TX-4-C53	1
27	Swivel Assembly	STX-4M-4M	2
28	Coupler Set	HC-S-100	1
40	Seal Insertion Tool	ATX-4-ST	
41	Gland Removal Tool	ATX-4-GW	

TX-4 Series Link




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Side Plate - Left	TX-4-L01- #*	1
2	Side Plate - Right	TX-4-L02- #*	1
3	Drive Plate	TX-4-L03- #*	1
4	Drive Pin	TX-4-L05	1
5	Drive Pin Spring	TX-4-L07	1
6	Ratchet	TX-4-L09- #*	1
7	Drive Segment	TX-4-L11- #*	1
8	Upper Spacer	TX-4-L13- #*	1
10	Lower Spacer	TX-4-L15- #*	1
11	Spacer Pin	TX-4-L17	2
12	Sideplate Sleeve	TX-4-L19- #*	2
13	Shroud	TX-4-L21	1
14	Segment Spring	TX-4-L25	1
15	Upper Spacer Screw	TX-4-L27	4
16	Lower Spacer Screw	TX-4-L29	4
17	Shroud Screw	TX-4-L31	2
18	Dr. Pin Spring Roll Pin	TX-4-L33	1

*part number is dependent upon ratchet link size


TX-8 Series Cylinder



Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Housing	TX-8-C01	1
2	Piston	TX-8-C03	1
6	Slider	TX-8-C09	2
7	End Cap	TX-8-C11	1
8	Retaining Ring	TX-8-C13	2
9	Link Pin	TX-8-C15	1
10	End Cover	TX-8-C17	1
11	End Cover Screw	TX-8-C23	1
14	Slider Pin	TX-8-C27	1
16	End Plug Seal	TX-8-C29	1
17	Rod Seal	TX-8-C31	1
19	Piston Seal	TX-8-C33	1
20	Cylinder Gland	TX-8-C51	1
21	Link Retaining Spring	TX-8-C53	1
27	Swivel Assembly	STX-4M-4M	2
28	Coupler Set	HC-S-100	1
40	Seal Insertion Tool	ATX-8-ST	
41	Gland Removal Tool	ATX-8-GW	

TX-8 Series Link




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Side Plate - Left	TX-8-L01- #*	1
2	Side Plate - Right	TX-8-L02- #*	1
3	Drive Plate	TX-8-L03- #*	1
4	Drive Pin	TX-8-L05	1
5	Drive Pin Spring	TX-8-L07	1
6	Ratchet	TX-8-L09- #*	1
7	Drive Segment	TX-8-L11- #*	1
8	Upper Spacer	TX-8-L13- #*	1
10	Lower Spacer	TX-8-L15- #*	1
11	Spacer Pin	TX-8-L17	2
12	Sideplate Sleeve	TX-8-L19- #*	2
13	Shroud	TX-8-L21- #*	1
14	Segment Spring	TX-8-L25	1
15	Upper Spacer Screw	TX-8-L27	4
16	Lower Spacer Screw	TX-8-L29	4
17	Shroud Screw	TX-8-L31	2
18	Dr. Pin Spring Roll Pin	TX-8-L33	1

*part number is dependent upon ratchet link size


TX-16 Series Cylinder



Part Numbers for Ordering

ITEM	NAME	PART #	QTY.	ITEM	NAME	PART #	QTY.
1	Housing	TX-16-C01	1	19	Piston Seal	TX-16-C33	1
2A	Piston Rod	TX-16-C03-1	1	20	Cylinder Gland	TX-16-C51	1
2B	Piston Cap	TX-16-C03-2	1	21	Link Retaining Spring	TX-16-C53	1
3	Valve Ball	TX-16-C03-3	1	22	Seal Plate	TXU-16-C54	1
4	Valve Spring	TX-16-C03-4	1	23	O-ring (Large)	USL-11	1
5	Valve Cup	TX-16-C03-5	1	24	O-ring (Small)	USL-13	4
6	Slider	TX-16-C09	2	25	Seal Plate Screw	USL-23	4
7	End Cap	TX-16-C11	1	27	Swivel Assembly	STX-4M-4M	2
9	Link Pin	TX-16-C15	1	28	Coupler Set	HC-S-100	1
14	Slider Pin	TX-16-C27	1	41	Gland Removal Tool	ATX-16-GW	
16	End Plug Seal	TX-16-C29	1	Piston Assembly (2A, 2B, 3, 4, 5)		TX-16-C03	
17	Rod Seal	TX-16-C31	1				

TX-16 Series Link




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Side Plate - Left	TX-16-L01- #*	1
2	Side Plate - Right	TX-16-L02- #*	1
3	Drive Plate	TX-16-L03- #*	1
4	Drive Pin	TX-16-L05	1
5	Drive Pin Spring	TX-16-L07	1
6	Ratchet	TX-16-L09- #*	1
7	Drive Segment	TX-16-L11- #*	1
8	Upper Spacer	TX-16-L13	1
9	Middle Spacer	TX-16-L14- #*	1
10	Lower Spacer	TX-16-L15- #*	1
11	Spacer Pin	TX-16-L17	2
12	Sideplate Sleeve	TX-16-L19- #*	2
13	Shroud	TX-16-L21	1
14	Segment Spring	TX-16-L25	1
15	Upper Spacer Screw	TX-16-L27	4
16	Lower Spacer Screw	TX-16-L29	4
17	Shroud Screw	TX-16-L31	2
18	Dr. Pin Spring Roll Pin	TX-16-L33	1
19	Spacer Roll Pin	TX-16-L35	1

*part number is dependent upon ratchet link size


TX-32 Series Cylinder



Part Numbers for Ordering

ITEM	NAME	PART #	QTY.	ITEM	NAME	PART #	QTY.
1	Housing	TX-32-C01	1	19	Piston Seal	TX-32-C33	1
2A	Piston Rod	TX-32-C03-1	1	20	Cylinder Gland	TX-32-C51	1
2B	Piston Cap	TX-32-C03-2	1	21	Link Retaining Spring	TX-32-C53	1
3	Valve Ball	TX-32-C03-3	1	22	Seal Plate	TXU-32-C54	1
4	Valve Spring	TX-32-C03-4	1	23	O-ring (Large)	USL-11	1
5	Valve Cup	TX-32-C03-5	1	24	O-ring (Small)	USL-13	4
6	Slider	TX-32-C09	2	25	Seal Plate Screw	USL-23	4
7	End Cap	TX-32-C11	1	27	Swivel Assembly	STX-4M-4M	2
9	Link Pin	TX-32-C15	1	28	Coupler Set	HC-S-100	1
14	Slider Pin	TX-32-C27	1	41	Gland Removal Tool	ATX-32-GW	
16	End Plug Seal	TX-32-C29	1	Piston Assembly (2A, 2B, 3, 4, 5)		TX-32-C03	
17	Rod Seal	TX-32-C31	1				

TX-32/45 Series Link




Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Side Plate - Left	TX-32-L01- #*	1
2	Side Plate - Right	TX-32-L02- #*	1
3	Drive Plate	TX-32-L03- #*	1
4	Drive Pin	TX-32-L05	1
5	Drive Pin Spring	TX-32-L07	1
6	Ratchet	TX-32-L09- #*	1
7	Drive Segment	TX-32-L11- #*	1
8	Upper Spacer	TX-32-L13	1
9	Middle Spacer	TX-32-L14- #*	1
10	Lower Spacer	TX-32-L15- #*	1
11	Spacer Pin	TX-32-L17	2
12	Sideplate Sleeve	TX-32-L19- #*	2
13	Shroud	TX-32-L21	1
14	Segment Spring	TX-32-L25	1
15	Upper Spacer Screw	TX-32-L27	4
16	Lower Spacer Screw	TX-32-L29	4
17	Shroud Screw	TX-32-L31	2
18	Dr. Pin Spring Roll Pin	TX-32-L33	1
19	Spacer Roll Pin	TX-32-L35	1

*part number is dependent upon ratchet link size

TX-45 Series Cylinder



Part Numbers for Ordering

ITEM	NAME	PART #	QTY.
1	Housing	TX-45-C01	1
2A	Piston Rod	TX-45-C03-1	1
2B	Piston Cap	TX-45-C03-2	1
3	Valve Ball	TX-45-C03-3	1
4	Valve Spring	TX-45-C03-4	1
5	Valve Cup	TX-45-C03-5	1
6	Slider	TX-45-C09	2
7	End Cap	TX-45-C11	1
9	Link Pin	TX-45-C15	1
14	Slider Pin	TX-45-C27	1
16	End Plug Seal	TX-45-C29	1
17	Rod Seal	TX-45-C31	1
18	Piston Cup Seal	TX-45-C32	1
19	Piston Seal	TX-45-C33	1
20	Rod Bushing	TX-45-C51	1
21	Link Retaining Spring	TX-45-C53	1
27	Swivel Assembly	STX-4M-4M	2
28	Coupler Set	HC-S-100	1
41	Gland Removal Tool	ATX-45-GW	

Piston Assembly (2A, 2B, 3, 4, 5) TX-45-C03

MAINTENANCE SECTION

WARNING

Always turn off the power supply. Bleed off hydraulic fluid from the hose connections on the cylinder assembly and disconnect the hoses before attempting to repair or perform maintenance on this tool. Always wear eye protection when operating or performing maintenance on this tool.

DISASSEMBLY

GENERAL INSTRUCTIONS

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. Use extra care not to score, nick or damage surfaces that will contain hydraulic oil under pressure.
3. Whenever grasping a tool in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.
4. Do not remove any part that is press fit in or on an assembly unless the removal of that part is necessary for repairs or replacement.
5. Do not disassemble the hydraulic cylinder assembly unless you have a complete set of seals and O-rings for replacement.
6. Use only British Standard fractional size tools when disassembling these tools.

DISASSEMBLY OF THE TOOL

1. Push the link pin (9) out of the housing (1) and side plates (1 & 2).
2. Lift the housing from between the side plates and separate the two units.

DISASSEMBLY OF THE TX-1 CYLINDER ASSEMBLIES

1. Clamp the housing in copper-covered or leather-covered vise jaws with the inlet end upward, using a wrench, unscrew and remove the two whip hoses (26) with their attached couplers (28).
2. Remove the housing assembly from the vise jaws and turn over a container to catch any oil remaining inside the cylinder.
3. Re-clamp the housing in the vise with the inlet end upward.
4. Using a wrench on the hex of the end plug wrench, unscrew and remove the end cap (7) with the end plug seal (16).
5. Using a socket on the hex of the piston cap (2B), unscrew and remove the piston cap from the piston rod (2A).
6. Remove the housing from the vise and turn over a container to empty any remaining oil from the housing.
7. Re-clamp the housing in the vise and remove the piston rod (2A) from the housing. If necessary, tap the threaded end of the piston rod with a brass tap being careful not to damage the threads.
8. Press the brass bushing (20), from the piston rod end of the housing, out of the housing.
9. To remove the sliders (6), position the slider pin (14) over a clearance opening in a soft block and use a small drift to tap the pin out of the sliders and the piston rod.

MAINTENANCE SECTION

DISASSEMBLY OF THE TX-2, TX-4, AND TX-8 CYLINDER ASSEMBLIES

1. Place the tool with the slider pin hole over a clearance opening and use a small drift to tap the slider pin (14) out of the sliders (6) and piston (2).
2. Clamp the housing in copper-covered or leather-covered vise jaws with the inlet end upward, using a 1/4" hex wrench, unscrew and remove the two swivel assemblies (27) with their attached couplers (28).
3. Remove the housing assembly from the vise jaws and turn over a container to catch any oil remaining inside the cylinder.
4. Re-clamp the housing in the vise with the inlet end upward.
5. Use a hex wrench to unscrew and remove the end cover screw (11). Remove the end cover (10).
6. Tap the end cap (7) inward approximately 1/2" and remove the two retaining rings (8) by working them out of the groove in the cylinder. **Note:** Covering the oil ports with a cloth will contain any oil that may expel from the housing.

CAUTION

The purpose of the seal insertion tool in the following step is to prevent the end plug seal from expanding into the retaining ring groove. If the tool is not used, place two thin pieces of flat stock at the midpoint of the opening against opposite walls to control the seal expansion.

7. Install the seal insertion tool (40) on the inlet end of the housing. **Note:** Lubricating the inside of the insertion tool will ease in the removal of the piston (2) and end cap (7).
8. Invert the tool above the vice. Place a cloth draped between the jaws of the vice to contain the exiting parts. Spread the vice open enough to catch the end plug and piston.
9. Tap the piston with a brass tap lightly until both the piston and end cap slip through the housing and into the catch cloth.
10. Use the gland removal tool (41) to unscrew and remove the cylinder gland (20) from the housing.
Note: The TX-2 does not have a cylinder gland.

NOTICE

During removal and after the piston shaft is removed; DO NOT grasp the round portion of the shaft with any holding device that will damage the surface. Any nicks or scratches to the surface will allow hydraulic oil to leak from the cylinder when the tool is reassembled.

DISASSEMBLY OF THE TX-16, TX-32 AND TX-45 CYLINDER ASSEMBLIES

1. Clamp the housing in copper-covered or leather-covered vise jaws with the inlet end upward, using a 1/4" hex wrench, unscrew and remove the two swivel assemblies (27) with their attached couplers (28).
2. Remove the housing assembly from the vise jaws and turn over a container to catch any oil remaining inside the cylinder.
3. Re-clamp the housing in the vise with the inlet end upward.
4. Using a socket on the hex of the end cap (7), unscrew and remove the end cap with the end plug seal.
5. Using a socket on the hex of the piston cap (2B), unscrew and remove the piston cap from the piston rod (2A).
6. Remove the housing from the vise and turn over a container to empty any remaining oil from the housing.
7. Re-clamp the housing with the end plug end upward in the vise. Place a cloth between the jaws of the vice to contain the exiting parts. Gently tap the piston rod (2A) with a brass draft to remove it from the housing, being careful not to damage the threads.

MAINTENANCE SECTION

8. Reclamp the housing in the vice so that the cylinder gland (20) is visible.
9. Use the gland removal tool (41) to unscrew the cylinder gland (20) from the housing.
10. Place the slider pin in the piston rod over a clearance opening in a soft block. Use a small drift to tap the pin out of the sliders and piston rod.

NOTICE

Under normal circumstances, the seal plate will not need to be removed for maintenance.

TO REMOVE SEAL PLATE ON TX-16 AND TX-32

1. Unscrew seal plate screws. (25)
2. Remove seal plate (22).
3. Inspect o-rings (23 & 24), replace if needed.
4. Insert seal plate into hole in housing.
5. Use a thread locking compound on plate screws before fastening seal plate to housing.

DISASSEMBLY OF THE RATCHET LINK

1. Lay the ratchet link flat on a workbench with the left side plate (1) downward and using a hex wrench, unscrew and remove the two lower spacer screws (16). **Note: TX-1 ratchet links do not have Upper Spacers or Lower Spacers.**
2. Using a hex wrench, unscrew and remove the two upper spacer screws (15). **Note: TX-1 ratchet links do not have Upper Spacers or Lower Spacers.**
3. **For series TX-16, TX-32, and TX-45 models:** Use a roll pin punch to tap the spacer roll pin (19) out of the right side plate (2).
4. While applying thumb pressure to the edge of the ratchet (6), carefully lift the side plate off the assembly.
5. Grasp the ratchet and drive plate (3) and, while maintaining their relationship, lift them both off the left side plate.
6. Push the ratchet out of the drive plate and remove the drive segment (7) and the segment spring (14) from the drive plate recess.

NOTICE

When the ratchet is removed from the drive plate, the drive segment and segment spring will be free to fall from the drive plate recess. Do not allow the drive segment to fall on a hard surface that might chip the teeth.

7. If the drive pin (4) or drive pin spring (5) must be replaced, use a roll pin punch to push the drive pin spring roll pin (18) out of the drive plate. Once the pin spring is removed, the drive pin (4) will drop down to the large opening at the bottom of the slot for easy removal.
8. Lift the lower spacer (10) off the lower spacer pins (11). If the pins must be replaced, use a hex wrench to remove the two lower spacer screws from the right side plate. Pull the pins out of the holes on the inner face of the right side plate.
9. **For Series TX-2, TX-4, and TX-8 models:** Unscrew the two spacer screws and remove the upper spacer (8) from the right side plate. **For Series TX-16, TX-32, TX-45 models:** Use a roll pin punch to remove the spacer roll pin (19) from the right side plate. Unscrew the two spacer screws and remove the middle spacer (9) and upper spacer (8) from the right side plate.
10. If the side plate sleeves (12) must be replaced, press the sleeves out toward the inner face of the side plate. **Note: TX-1 ratchet links do not have Upper Spacers or Lower Spacers.**

MAINTENANCE SECTION

NOTICE

Inspect all parts prior to assembly. Replace any worn or damaged parts.

ASSEMBLY

ASSEMBLY OF TX-1 CYLINDER ASSEMBLIES

1. Press the slider pin (14) into one of the sliders (6) until flush with one side. Install the pin through the hole in the piston rod (2A) and press the remaining slider into the pin.
2. With the inlet end of the housing upward, press the brass bushing (20), with the shoulder trailing, into the housing.
3. Clamp the housing in copper-covered or leather-covered vise jaws with the inlet end downward.
4. Insert the piston rod (2A), threaded end leading, into the small central opening in the housing. The notch in the trailing end of the rod should be towards the retaining pin hub.
5. Reclamp the housing in the vise with the inlet end upwards.
6. Insert the piston cap (2B), hex end trailing, into the bore of the housing and use a socket to thread and tighten the piston cap onto the piston rod.
7. Thread the end cap (7), O-ring leading, into the bore of the housing and tighten.
8. Wrap the threads of the whip hoses (26) with Teflon tape.
9. Install the male coupler hose into the end cap port and the female coupler hose into the housing port

ASSEMBLY OF TX-2, TX-4, AND TX-8 CYLINDER ASSEMBLIES

1. Clamp the housing (1) in copper-covered or leather-covered vise jaws with the inlet end downward.
2. Apply a non-permanent thread-locking compound to the threads of the cylinder gland (20). Use the gland removal tool (41) to thread the bushing into the small central opening in the housing and tighten until flush with the housing (1). **Note: TX-2 does not have a cylinder gland.**
3. Flip the housing (1) in the vise and install the seal insertion tool (40). **Note:** Lubricating the inside of the insertion tool and the sides of the piston rod assembly and end cap will ease installation.
4. Insert the piston (2) into the seal insertion tool (41), notched end leading and toward the link pin hub, and tap into housing approximately 1".
5. Insert the end cap (7), swivel inlet toward the link pin hub, into the seal insertion tool (40), and tap in until the piston (2) bottoms out against the housing (1).
6. Install retaining rings (8), tapered edge leading into the grooves in the housing.
7. Flip the housing in the vise and drive the piston (2) into the housing with a brass tap until the end cap (7) seats in the retaining rings (8).
8. Install the end cover (10), applying a non-permanent thread-locking compound to the end cover screw (11) threads.
9. Remove the housing from the vice and place on a soft block with the engraved side up.
10. Install sliders (6), one on each side of piston (2). **For TX-8 models:** Install sliders with the cutout towards the piston. Align the holes in the sliders with the holes in the piston and the housing.
11. Install slider pin (14) until flush with top slider.
12. Apply moly grease to the face of the sliders and the notch in the piston.
13. Wrap the threads of the swivel assemblies (27) with Teflon tape.
14. Install the male coupler swivel into the end cap port and the female coupler swivel into the housing.

MAINTENANCE SECTION

NOTICE

Inspect all parts prior to assembly. Replace any worn or damaged parts.

ASSEMBLY OF TX-16, TX-32 AND TX-45 CYLINDER ASSEMBLIES

1. Press the slider pin (14) into one of the sliders (6) until flush with one side. Install the pin through the hole in the piston rod (2A) and press the remaining slider into the pin.
2. Clamp the housing in copper-covered or leather-covered vise jaws with the inlet end downward.
3. Apply a non-permanent thread-locking compound to the threads of the cylinder gland (20). Use the gland removal tool (41) to thread the gland into the small central opening in the housing and tighten until flush with the housing (1).
4. Insert the piston rod (2A), threaded end leading, into the small cylinder gland in the housing. The notch in the trailing end of the rod should be towards the retaining pin lug.
5. Reclamp the housing so that the inlet end is upwards.
6. Insert the piston cap (2B), hex end trailing, into the bore of the housing and use a socket to thread and tighten the piston cap onto the piston rod.
7. Thread the end cap (7), O-ring leading, into the bore of the housing and tighten with a socket.
8. Wrap the threads of the swivel assemblies (27) with Teflon tape.
9. Install the male coupler swivel into the end cap port and the female coupler into the housing port.

ASSEMBLY OF THE RATCHET LINK

1. If the side plate sleeves (12) were removed, press new sleeves, shoulder end trailing, into the right and left side plates (1 & 2) from the inner face of the side plates. Make certain the sleeves are square with the side plate faces and that the shoulder of the sleeves enters the recesses in the side plates and are pressed flush with the faces.
2. **For Series TX-2, TX-4, and TX-8 models:** Position the upper spacer (8) against the inside face of the right side plate. Apply a non-permanent thread-locking compound to the threads of the two upper spacer screws (15) and secure the spacer with the screws through the side plate. **For Series TX-16, TX-32, TX-45 models:** Press the spacer roll pin (19) into the right side plate with one end of the pin flush with the external face of the side plate. Insert the tab of the upper spacer (8) into the slot in the middle spacer (9). After aligning the holes in both pieces, install them on the spacer roll pin (19). When they are correctly positioned, apply a non-permanent thread-locking compound to the threads of the two upper spacer screws (15) and secure the spacers with the screws through the side plate.
3. Insert the two lower spacer pins (11) into the holes in the lower edge of the right side plate. Apply a non-permanent thread-locking compound to the threads of the lower spacer screws (16) and secure the pins with the screws through the side plate. **Note: The TX-1 ratchet links do not have Upper Spacers and Lower Spacers.**
4. Place the lower spacer (10) over the pins against the side plate. Make certain it is correctly oriented so that no part of the spacer extends beyond the edge of the side plate. **Note: The TX-1 ratchet links do not have Upper Spacers and Lower Spacers.**
5. Insert the drive pin (4) into the small cross-hole and slot in the drive plate (3). Invert the plate causing the ends of the pin to enter the slot and move the pin to the narrow end.
6. Position the drive pin spring (5) in the drive plate slot with the two non-connected ends between the drive pin and the large hole in the slot. Position the closed end of the spring on the opposite side of the pin and then apply pressure on the spring to align the hole through it with the hole in the drive plate for the drive pin spring roll pin (18). Insert the spring roll pin into the drive plate, through the spring and into the far wall of the drive plate.

MAINTENANCE SECTION

NOTICE

In the following step, an excessive amount of grease will prevent proper tooth engagement between the ratchet and the drive segment, causing the tool to malfunction.

7. Wipe a thin film of Marine Moly Grease onto the inner face of the large opening in the drive plate.
8. Position the ratchet (6) in the central opening of the drive plate.
9. Insert the drive segment (7) into the opening adjacent to the ratchet. **Make certain the teeth of the ratchet correctly engage the teeth of the drive segment.** Reverse the ratchet if they do not properly engage.
10. Slide the drive segment sideways to expose the spring hole. Install the segment spring (14) into the hole. While compressing the spring, slide the drive segment inward until the drive plate captures the segment spring.
11. Apply a light coat of Marine Moly Grease to both sides of the drive plate and drive segment as well as the inner races of both side plate sleeves (12).
12. While keeping the assembly together, insert the hub of the ratchet into the side plate sleeve of the assembled side plate.
13. Place the left side plate sleeve on the hub of the ratchet and align the screw holes for the spacers.
14. After applying a non-permanent thread-locking compound to the threads and using hex wrenches, install the two remaining lower spacer screws.

ASSEMBLY OF THE TOOL

1. With the cylinder assembly in one hand and the ratchet link in the other, hook the notch on the shaft of the piston rod (2A) onto the drive pin (4) and bring the two assemblies together.
2. Insert the link pin (9) into the hole in the side plate (1 or 2) until the link pin snaps into the link retaining spring (21).

TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Piston will not advance or retract	Couplers are not securely attached to the tool or pump	Check the coupler connections and make certain that they are connected.
	Coupler is defective	Replace any defective coupler.
	Defective remote control switch	Replace the switch and/or control pendant.
	Dirt in the direction-control valve of the pump unit	Disassemble the pump and clean the direction-control valve.
Piston will not retract	Hose connections reversed	Make certain the advance on the pump is connected to the advance on the tool and retract on the pump is connected to the retract on the tool.
	Retract hose not connected	Connect the retract hose securely.
	Retract pin and/or spring broken	Replace the broken pin and/or spring.
Cylinder will not build up pressure	Piston seal and/or end plug seal leaking	Replace any defective o-rings.
	Retaining screws sheared	Replace any broken screws.
	Coupler is defective	Replace any defective coupler.
Ratchet will not turn	Grease or dirt build up in the teeth of the ratchet link and drive segment	Disassemble the ratchet and clean the grease or dirt out of the teeth.
	Worn or broken teeth on ratchet and/or drive segment	Replace any worn or damaged parts.
Tool tightens immediately when turned on	Hose connections are reversed	Depress the advance button to release the tool; shut the pump off in the advance position and reverse the hose connection.
Pump will not build up pressure	Defective relief valve	Inspect, adjust or replace the relief valve.
	Air supply too low or air hose too small	Make certain the air supply and hose size comply with the pump manual recommendations.
	Electric power source is too low	Make certain the amperage, voltage and any extension cord size comply with the pump manual requirements.
	Defective gauge	Replace the gauge.
	Low oil level	Check and fill the pump reservoir.
	Clogged filter	Inspect, clean and/or replace the pump filter.
Pressure reading erratic	Defective gauge	Replace the gauge.

SAVE THESE INSTRUCTIONS DO NOT DESTROY

NOTES:



1025 Conroy Place, Easton, PA. 18040 U.S.A.

Phone: +1 610-250-5800
Fax: +1 610-250-2700
Toll Free: 1-888-TORCUP-1
Email: sales@torcup.com
Website: www.torcup.com